

Dosing guidelines


1 notch	0.01 mL
1 line-to-line (1/3 of a turn)	0.05 mL
1 full turn	0.15 mL

Extracts have different specific gravities, usually ranging from 1.05 - 0.95 g/mL

HOW TO DISPENSE

Bring the level of oil to the tip of the nozzle. This step is achieved by gradually turning the threaded piston in a clockwise direction. Now that the oil is at the surface of the nozzle create your dose by following the guidelines above.

Always remember to release the pressure in the system by backing off the gasket. To achieve this important step turn the piston in a counter clockwise direction, until the piston is not engaged with the gasket.



EOS DISPENSER USER MANUAL

Threaded Piston

Piston Housing with scale


Pressure Fitted Gasket

BIA 2 mL / 5 mL Cartridge*

Dispensing Nozzle

Nozzle Cover

Cartridge Cap



*Pictures are applicable to 2 mL and 5 mL cartridges

Assembly guidelines

1

Remove the cartridge cap from the **cartridge**. Firmly install the dispensing nozzle.



2

Assemble your EOS. Assemble casing, housing disc and threaded piston.



3

To dispense the product slowly turn the **piston clockwise**. Each notch on the scale dispenses 0.01 mL. Wait a few seconds to dispense desired amount of extract if using thicker materials.



4

For storage turn the piston **counter-clockwise**. It is important to back the piston right off the gasket to remove all pressure from the system. After that place the nozzle cover on the nozzle.



Pictures and instructions are applicable to **EOS Dispenser 2 mL or 5 mL**.

Caution: Dropping EOS Dispenser may result in nozzle breakage. Store dispenser properly after use.